

# combo amplifier for acoustic instruments

# **IMPORTANT SAFETY INSTRUCTIONS**



THE LIGHTNING FLASH WITH ARROWHEAD SYMBOL, WITHIN AN EQUILATERAL TRIANGLE, IS INTENDED TO ALERT THE USER TO THE PRESENCE OF UNINSULATED "DANGEROUS VOLTAGE" WITHIN THE PRODUCT ENCLOSURE THAT MAY BE OF A SUFFICIENT MAGNITUDE TO CONSITUTE A RISK OF ELECTRIC SHOCK TO PERSONS.

THE EXCLAMATION POINT WITHIN AN EQUILATERAL TRIANGLE, IS INTENDED TO ALERT THE USER TO THE PRESENCE OF IMPORTANT OPERATING AND MAINTENANCE INSTRUCTIONS IN THE LITERATURE ACCOMPANYING THE PRODUCT.

# **WARNING**

# TO REDUCE THE RISK OF FIRE OR ELECTRICAL SHOCK DO NOT EXPOSE THE APPLIANCE TO RAIN OR HUMIDITY

- 1) Read these instructions.
- 2) Keep these instructions.
- 3) Heed all warnings.
- 4) Follow all instructions.
- 5) Do not use this apparatus near water.
- 6) Clean only with dry cloth.
- 7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9) Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 10) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 11) Only use attachments/accessories specified by the manufacturer.
- 12) Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



- 13) Unplug this apparatus during lightning storms or when unused for long periods of time.
- 14) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

## **WARNINGS**

## **PRECAUTIONS**

## **WARNINGS**

Please read this manual carefully before using your GIULIAY amplifier and observe all safety precautions

**Keep this manual for future reference** 

Do not pour any liquids onto this device, or operate it in excessively humid conditions.

Do not use or install this device near sources of excessive heat. Do not expose it to direct sunlight, or position it in a dusty environment without any form of protection.

Ensure that the mains voltage does not exceed the value indicated on the back panel.

Do not use this device if either the mains cable or its plug is not in perfect condition. (Replace if necessary.)

If the mains cable needs replacing, it must be done by an appropriately qualified person. The replacement cable must be exactly the same as the original.

To avoid interference, do not use this device near power transformers, TVs, RF transmitters, electric motors or any other source of electrical energy.

Do not point a microphone towards any speakers as this could result in feedback (Larsen effect) and ultimate damage to your device.

Only use the original connection cables – if supplied with the device. Otherwise this could prove both costly and inconvenient.

To completely disconnect this device from the AC mains, remove the power cable plug from the mains socket.

When cleaning, do not use solvents (e.g acetone or alcohol). These could damage the external finish and the serigraphy.

Do not attempt to service this device. If any malfunction is detected, call the nearest technical assistance centre, or a specialist technical centre.

To maintain good ventilation, never cover or obstruct the heat sink with blankets, sofas or any other furnishings.

Always leave sufficient clearance between the heat sink and any other surface.

No flammable sources, i.e. candles, should be placed on or near the device.

This device should never be exposed to water, even in small amounts. No object containing liquids should be placed on or near the device.

This device should only be connected to a mains socket outlet that has a protective ground.

When using or installing this device, always make sure that the mains socket and the mains cable plug are easily accessible.

# INTRODUCTION

GIULIA Y is the latest addition to Schertler's range of high-quality, compact acoustic amplifiers. While retaining many of the features of its smaller sibling GIULIA, this new 2-channel model has enhanced circuitry and a new "look" that heralds the next generation of Schertler's amplifier technology.

Perfect for small venues, home studios or for practice, GIULIA Y offers 50W of bi-amplified power. Both input channels can accommodate XLR and 1/4" Jack connectors, making the amp suitable for use with a wide range of microphones including Schertler's DYN and STAT series, or the BASIK pickup. Phantom power (24V and 10V) is supplied. The inputs can also be used for guitars or other high level line sources, with the amplifier's intelligent electronics automatically adapting to suit. The Master channel has 3-band EQ and Warm low-pass filter to produce a warmer sound when used with bridge-mounted pickups. Separate Line and DI outputs enable connection to a mixer, subwoofer or other external device.

GIULIA Y also has a high-quality digital reverb (controlled via potentiometer) and an Insert socket, enabling the connection of an external dynamics processor or a volume pedal.

# PRACTICAL ADVICE

When you are using an amplified speaker, one of the most important recommendations is to avoid at all costs a distorted input signal.


In other words, when you are controlling the sound in your amplifier's mixer section (or any other preamplifier), you must avoid reaching saturation level.

While playing your instrment or singing in the microphone, start turning up the Gain knob until the Overload LED begins to blink. At this point, turn the Gain knob back down slightly. This correctly sets the preamp level depending on your actual input signal. Now set the Master volume between 30% and 60%. With the Gain and Master levels appropriately set, you can now set the channel volume as you please.

In the case of amplified speakers, the arrival of a distorted signal (square wave) may damage the internal amplifier beyond repair, which may in turn damage the loudspeakers.

Correct use of speakers guarantees their long life.

# 1. FRONT PANEL - INSTRUMENT IN



## 1.1. MIC INPUT

This input is electronically balanced for XLR type connections. The new MIC/DYN channel is now conceived for any kind of signal sources. You can plug in vocal microphones. The electronics will adapt to any situation. No special action is required.

#### 1.2. P24

The amplifier's XLR input provides 24V phantom power for use with a condenser microphone. Most condenser (and dynamic) microphones, along with some preamps, can be safely phantom powered. In certain cases however, phantom power can cause damage to a device.

This tends to occur with unbalanced microphones, preamps or stompboxes that have been modified for balanced XLR use.

If in doubt, please contact us to check the compatibility of your audio device before using the amplifier

#### 13 10\/

Phantom power supplies the Jack connector with 10V for powering electret microphones.

#### 1.4 STAT IN

Unbalanced input for the connection of jacks (6.3mm or 1/4"), with optimal sensitivity for high level sigals, The electronics will adapt to any situation. No special action is required.

## 1.5. GAIN MIC

This variable gain preamplifier adjusts the sensitivity level to ensure the best possible processing of the MIC signal through the channel.

It is important that this input level should be set and optimised in the best way to achieve the cleanest sound possible.

## 1.6. GAIN INSTRUMENT

This variable gain preamplifier adjusts the sensitivity level to ensure the best possible processing of the STAT signal through the channel.

It is important that this input level should be set and optimised in the best way to achieve the cleanest sound possible.

## 1.7. HIGH, MID, LOW

These controls are devoted to high, medium and low frequency regulation. Offering cut and boost of ±15dB, they allow a wide range of tonal variations to be explored. When the controls are positioned centrally there is no cut or boost of the selected frequency band. The adjustment is on both channels

## 1.8. WARM

When engaged, this low-pass filter damps higher frequencies to produce a warmer sound when using bridge-mounted pickups such as the SCHERTLER STAT-Series transducers for violin, cello and double bass.

## 1.9. REVERB

This rotary control sets the level of the digital reverb on both channels.

## 1.10. MASTER

This rotary control regulates the Master on both channels.

## 1.11. LINE-OUT

This unbalanced jack plug enables the connection of external systems. The output volume depends on the regulation of the MASTER-VOL.


## 1.12. INSERT

This stereo jack plug enables the connnection of an external device (compressor, equalizer, etc.) in series to all the outputs.

## 1.13. DI-OUT

General output. XLR balanced type connector for connections of external systems. The output volume does not depend on the regulation of the MASTER-VOL but is effected by changes in the channel volume.

# 2. REAR PANEL



2.1. POWER ON/OFF System ON/OFF switch.


## 2.2. GROUND LIFT

This switch connects and disconnects the ground

## 2.3 MAIN POWER CONNECTION

PLEASE ENSURE THE PROPER VOLTAGE AND USE THE ORIGINAL CONNECTION CABLE

# **SIGNAL FLOW**



# **TECHNICAL SPECS**

Frequency response  Sensitivity (1W-1m)  SPL max  Woofer  Horn  Crossover	88.5 dB 104 dB 5" Dome 1"
Box	Bass reflex
Construction	Birch laminated
System – Format	. 2-way, Bi-amp
Max Power out	30 W + 20 W
Weight	6.8 Kg
Dimensions	270 x 180 x 280 mm.
INPUTS	
MIC IN	
Connector	XLR balanced
Sensitivity	
Impedance	4.7 kohm
LINE IN	
Connector	
Sensitivity	-47 dB
Impedance	820 kohm
OUTPUTS	
LINE OUT	
Connector	
Level	
Impedance	200 ohm
D.I. OUT	
Connector	
Level	-15 dBu
Impedance	200 ohm
INSERT	
Connector	Jack 6.3 mm.
INTERNAL EFFECT (digital reverb) Frequency response	200Hz - 10kHz
Delay time	
Reverb time	c.a. 2.8 s.

ALL SCHERTLER® PRODUCTS ARE COVERED BY A LIMITED THREE-YEAR WARRANTY (FROM THE DATE OF PURCHASE) AGAINST MANUFACTURES DEFECTS. DETAILS CAN BE OBTAINED FROM YOUR LOCAL DEALER/REPRESENTATIVE. SCHERTLER SA STRONGLY BELIEVES IN "COMMON SENSE" AND THUS, MISUSE OF OUR PRODUCTS ARE NOT COVERED UNDER RIGHTS OBTAINED THROUGH OUR WARRANTY POLICY OR THAT OF INTERNATIONALLY RECOGNIZED TERMS AND CONDITIONS.
SCHERTLER SAIS CONSTANTLY AIMING TO IMPROVE ITS RANGE OF PRODUCTS THEREFORE, SCHERTLER SA RESERVES THE RIGHT TO AMEND PRODUCT SPECIFICATIONS WITHOUT NOTICE.
THE SCHERTLER® NAME/LOGO ARE REGISTERED TRADE-NAMES/ TRADEMARKS OF

All SCHERTLER® PRODUCTS ARE OF PROPRIETARY TECHNOLOGY AND COVERED BY ONE

SCHERFLER®

ACOUSTIC AMPLIFICATION

SWISS MADE | schertler.com

SCHERTLER SA, SWITZERLAND.

OF MORE WORLDWIDE PATENTS.

TEL+41916300710 FAX+41916300711 info@schertler.com SCHERTLER SA Via Beroldingen 18 6850 Mendrisio