
# SCHERFLER



THANK YOU FOR CHOOSING SCHERTLER



# **CONNECTIONS**

Instruments input

Microphones input

(condenser or dynamic) or DYN contact microphones Instruments input



TO external effects

FROM external effects

**BALANCED** output

to mixer

LINE stereo

input

**UNBALANCED** 

output to monitor

## **QUICK START**

### TURN ON THE AMP

Check the MASTER volume, GAIN and channel VOLUME potentiometers are completely closed or the MUTE is activated.

Connect the power cable to mains and switch on the amp.

If a ground noise (hum at 50-60Hz) occurs, flip the ground lift switch (GND LIFT) on the rear panel.

### **CONNECTIONS**

Connect a microphones to the XLR or instruments to the ½"jack sockets. Remember to activate the P24 phantom power on the XLR when using condenser microphones and DYN P48 contact microphones or the 10V on the ½"jacks when using STAT pickups or other electrostatic microphones.

### **LEVELS SET UP**

Playing (or singing) loud, turn the GAIN up until the OL red LED starts to blink, from there turn it back down a little. Now open the MASTER between 30% and 50% finally adjust CHANNEL VOLUME as needed.

### OTHER FEATURES


Once the levels are properly set, you can shape your sound with the EQ and the WARM filter (on ch. 1) or cut the selectable 150 Hz or 240 Hz with the RESON notch filter (on ch.2) and set the amount of REVERB you want on each channel and its return on the MASTER. The LOW CUT button will high pass the signal to the speakers.


### **EXTERNAL EFFECTS**

You can connect external effect on the MASTER (affecting both channels) using a Y-cable: connect the stereo jack to the INSERT socket and the two mono jacks to the input and output of the external pedal.

USER MANUAL available online at www.schertler.com

# **RELATED PRODUCTS**





Schertler SA
Via Beroldingen 18
6850 Mendrisio
Switzerland
T +41 (0)91 630 07 10
F +41 (0)91 630 07 11

info@schertler.swiss www.schertler.swiss Facebook @schertler.sa Instagram @schertleraudio Youtube @Schertler SA #shareyourschertler Scan the QR code to open the USER MANUAL

